

## Rollei



### 20 Megapixel Sony Sensor

- ▶ 4 x Optical Zoom
- ▶ 720p HD Video Function (1280 x 720/30 fps)
- ▶ 2.7" LCD Panel (9.6 cm, 230K)
- ▶ Waterproofed up to 10 meters
- ▶ Photo Time Lapse Function (30 seconds, 1/5/10/30/60 minutes)



### Top Details

- ▶ Always sharp picture, automatically!!!!
- ▶ Super Macro 5 cm
- ▶ 28 Scene Modes, incl. Time Lapse, Panorama, Speedy Burst
- ▶ Video: up to 29 minutes recording time
- ▶ With built-in speaker and microphone

### Technical features

<b>Image sensor</b>	20 megapixels Sony sensor
<b>Resolution</b>	Still Image: 20 MP (5152 x 3864), 8 MP (3264 x 2448), 5 MP (2592 x 1944), 3MP (2048 x 1536), VGA (640 x 480)   Video: 1280 x 720 /30 fps, 640 x 480
<b>Lens</b>	Lens construction: 6 groups, 6 elements (2 glass and 4 plastic lens)   Aperture: F= 1:3.2 (W) ~ 5.8 (T)   f= 4.6 ~ 18.4 mm, equivalent to 26 – 104 mm in 35 mm film format
<b>Zoom</b>	4 x optical zoom
<b>Display</b>	2.7" LCD Panel (9,6 cm, 230K), 4:3
<b>ISO</b>	Auto, 100, 200, 400, 800, 1600, 3200, 6400
<b>Data Format</b>	Still Image: JPG (EXIF 2.3)   Video: AVI   Sound: WAV
<b>Memory Card Slot</b>	for microSD up to 4 GB, microSDHC up to 32 GB, UHS-1 speed card
<b>System Requirements</b>	PC: Windows XP (SP 2/SP3), Vista, Win 7, Win 8   Mac: OS 10.8 or later
<b>Connectors</b>	miniUSB, USB 2.0 Full Speed, AV (NTSC/PAL)
<b>Power</b>	rechargeable Lithium-ion Battery (3.7 V / 700 mAh)
<b>Dimension</b>	107.5 x 66.1x 50.45 mm
<b>Weight</b>	162 g (without battery and SD card)
<b>Accessory</b>	USB cable, hand strap, battery and quick start guide

Subject to technical changes.



I like – on  
facebook.com/rollei.photo.en

Orange



Green



Blue

